

Why not 50 - Comet watch dogs --
life long friends --

In your home installation - use one for
500 cu ft in oil heater room -- and where
oils are used -- otherwise on other
side -- bear in mind that closets and attics
are sources of unexplained fires -- but
generally combustion -- piles of clothes
and piles of anything have a way of combust-
ing -- there is ~~is~~ one way to KNOW that
there is no chance - even short circuit
fires -- Comets kill them until they
burn away the short -- the contents
and gas of a Comet is a NON CON-
DUCTOR --

Red Comets will be watch dogs over
all the things you have assembled there
- your books -- no more cost -- no bother
- they are permanent and reliable -- --
for life -- and on -- best wishes --

Holland -

Dont lock your home and fail to leave Comets on guard
if a fire department got there - the water would ruin it all.

BUY U.S.
BO
ASK YOUR



Mr. Ernest Hemming
Key West - Fla

L-J. Ranch
Leavelle City
Mont.

FOR FIRE

(Put this card by each Red Comet and instruct employes)

Manual Use—Throw Grenade at edge of flame to splash Fluid over entire burning area. Keep doors and windows closed. For motors throw directly onto fire. For chimney fires throw in stove or furnace and shut door.

Automatic Use—Red Comet Automatics work whether a human being is present or not, when fire breaks out as the fuses melt at about 160° of heat, releasing the powerful spring which crashes the heavy slug into the glass grenade and scatters the fluid in midair. The fluid immediately gassifies, and is drawn by the draft, to the fire. This keeps the oxygen away so the fire can be smothered.

Installation—IN ORDINARY RISKS we recommend placing the Standard Size Wall Type Red Comet Automatics so no fire could start more than 6 to 7 feet away, up, down, or sideways, and the Standard Ceiling Types within 7 to 8 feet of each other. IN SEMI-DANGEROUS RISKS we recommend placing the Standard Size Wall Type Red Comet Automatics so that no fire can start more than 5½ to 6 feet away, and the Standard Ceiling Types within 6 to 7 feet of each other. IN DANGEROUS RISKS we recommend placing Standard Size Wall Type Red Comet Automatics so that no fire can start more than five feet away in any direction, and if where the fire must be stopped almost instantly on account of valuable records, etc., place Red Comet Ceiling Type Automatics four feet from each other.

After Use—Be sure to notify Red Comet, Inc., Littleton, Colo., and we will have our nearest Representative get in touch with you at once. Do not be without Red Comet protection.

Caution—This Red Comet is placed here for your protection, do not handle except for fire.

Red Comet,  Incorporated

Mfrs. of Red Comet, the original and genuine Automatic
(Automatic Fire Extinguisher Headquarters)
LITTLETON, COLORADO, U. S. A.